

Mobile Fencing & Security



Off-hire instructions

Please help us to help you.
Thank you for your cooperation

www.heras-mobile.co.uk

HERAS
A CRH COMPANY

Off-hire instructions

To ensure that, when you have finished with the fencing, the collection runs as smoothly as possible please take note of the following polite requests.

1. Dismantling the fencing

All fencing needs to be dismantled & neatly stacked before our drivers turn up on site.

Please ensure materials are returned in the same condition as issued - remove signs, netting, weeds & separate any damages if applicable.



2. Site presence

Heras requests & assumes that there is someone on site, regardless whether the fencing is being lifted by hand or by crane. This allows you to sign off & check the quantity & conditions of returns & to ensure all equipment you want to return is returned. Our drivers will not go looking for missing equipment.



3. Please have all materials fully accessible in close proximity to the loading vehicle

Our drivers will not walk materials over large distances or over obstacles.





4. Loading the materials

Please note it is very much the hirer's responsibility to load the fencing back onto the collection vehicle. Our driver can not be expected to load any quantity by themselves outside their personal capability.

Crane loading is available only if specifically agreed beforehand. If materials are to be loaded by crane then it is the site's responsibility to ensure that the materials are in a condition to be loaded by a crane operation, to be within the crane's maximum reach of approx. 2 mtrs and that there is a designated lifting zone, away from passing traffic or pedestrians.



5. Stacking

Items must be properly stacked to allow a crane operation to be carried out.

Please see overleaf for specific stacking instructions for our most popular products.

Stacking

Mesh fencing panels

- To stack panels neatly in bundles no more than 30 panels high
- Do not lay vertically against a wall
- Top & tail "round top" panels
- To raise panels off the floor to allow the driver to get his slings underneath – either using bearers or blocks



- as will not go on vehicle safely.
- all will need to be re-stacked, site assistance may be necessary.

Blocks

- Hi-vis blocks to be loaded on euro-pallets in quantities of no more than 40
- Bottom row of black blocks turned on side to allow forks or slings to be passed thru'





Readyboard panels

- To stack panels neatly in bundles no more than 25 panels high.
- Do not lay vertically against a wall
- To raise panels off the floor to allow the driver to get his slings underneath – either using bearers or blocks



Fixed leg bar barriers

- To stack vertical in quantities no more than 25
- To invert each alternate barrier – lie the 1st barrier in an upwards direction, the 2nd upside down etc etc



Bar barriers (separate baseplates)

- To stack horizontal in quantities no more than 30
- To top & tail (each barrier laid out alternatively)



Acoustic barriers

- No more than 30 stacked alternately
- Stacked on pallets folded in half



Avalon barriers

- No more than 30 stacked alternately
- Stacked top and tailed

Mobile Fencing & Security

Unit B1
Castle Road
Eurolink Industrial Estate
Sittingbourne
Kent, ME10 3RL

T 0844 472 0011
E sales@heras-mobile.co.uk

www.heras-mobile.co.uk



National Control Centre

0844 472 0011

Scottish Call Centre

01236 749995